

# Анализаторы химического состава Liquiline System CA80NO

## Техническая информация

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

эл.почта: [ehr@nt-rt.ru](mailto:ehr@nt-rt.ru) || сайт: <https://endcounters.nt-rt.ru/>

# Nitrite analyzer

## Liquiline System CA80NO

Colorimetric system for monitoring of drinking water, mineral water or raw water for food production



### Benefits:

- Compliance with standard colorimetric measuring principle - naphthylamine method - following ISO 6777 and DIN EN 26777 ensures comparability to lab measurements.
- Reduced operating costs through automatic calibration and cleaning.
- Simple maintenance: no tools required.
- Advanced diagnostics with remote access for increased process safety.
- Fast commissioning and plug & play thanks to Memosens technology and user-friendly operation.
- Easy upgrade of functionality - even to a complete measuring station - simply by adding modules and connecting Memosens sensors. Reduces installation effort.

### Specs at a glance

- **Measurement range** 10 to 500 µg/l NO<sub>2</sub>-N 0.2 to 3.0 mg/l NO<sub>2</sub>-N 0.1 to 1.0 mg/l NO<sub>2</sub>-N 0.1 to 1.0 mg/l with dilution function to maximum 5 to 50 mg/l NO<sub>2</sub>-N
- **Process temperature** 4 to 40 °C (39 to 104 °F)
- **Process pressure** At atmospheric pressure, < 0.2 bar absolute

**Field of application:** Liquiline System CA80NO offers precise, regulation-compliant online measurement of nitrite. It supports you in meeting the specified limits in drinking water, mineral water or food production. Like all Liquiline System analyzers, it enables plug & play of up to four Memosens sensors – minimizing the installation effort. Automatic calibration and cleaning and the low reagent consumption reduce

operating and maintenance costs. Advanced diagnostics with remote access ensure process safety.

## Features and specifications

### Analyser

**Measuring principle**

Colorimetric

**Characteristic**

Process analyzer for Nitrite in potable water

**Size**

Housing (open version):

793 x 530 x 417 mm

31.22 x 20.87 x 16.42 in

Housing (closed version):

793 x 530 x 463 mm

31.22 x 20.87 x 18.23 in

Housing with base:

1723 x 530 x 463 mm

67.83 x 20.87 x 18.23 in

**Design**

Open design, cabinet and stand housing

High-Performance plastic ASA-PC, additional stand coated steel

**Process temperature**

4 to 40 °C (39 to 104 °F)

**Ambient temperature**

5 to 40 °C (41 to 104 °F)

Outdoor version: - 20 to 40 °C (-4 to 104 °F)

**Process pressure**

At atmospheric pressure, < 0.2 bar absolute

**Sample flow rate**

Min. 5 ml/min (0.17 fl.oz/min)

---

## Analyser

### Consistency of the sample

Suspended solids content

Turbidity < 50 NTU, aqueous, homogenized

---

### Specials

Easy upgrade to measuring station with up to four digital Memosens sensors

Automatic calibration and cleaning

User-configurable measuring, cleaning and calibration intervals

Optional cooling module for standard solution

2 channel version optional

User-definable measuring ranges

Modular design for easily extensible functionality

---

### Application

Limit value monitoring of nitrite for potable water and mineral water applications

---

### Power supply

100 to 120 VAC / 200 to 240 VAC  $\pm$  10%

24 VDC  $\pm$  10%

50  $\pm$  1 or 60  $\pm$  1,2 Hz

---

### Output / communication

2x 0/4 to 20 mA

Modbus RS485/TCP (optional)

Ethernet (optional)

Alarmrelay

---

### Input

1 or 2 measuring channel

1 to 4 digital sensor inputs for sensors with Memosens protocol (optional)

---

## Analyser

### Measurement range

10 to 500 µg/l NO<sub>2</sub>-N

0.2 to 3.0 mg/l NO<sub>2</sub>-N

0.1 to 1.0 mg/l NO<sub>2</sub>-N

0.1 to 1.0 mg/l with dilution function to maximum 5 to 50 mg/l NO<sub>2</sub>-N

---

### Consumables

Reagents and standard solutions CY80NO as well as cleaner CY800 are necessary for the operation

Regular maintenance is done with the parts of the maintenance kit CAV800

---

## По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231  
Ангарск (3955)60-70-56  
Архангельск (8182)63-90-72  
Астрахань (8512)99-46-04  
Барнаул (3852)73-04-60  
Белгород (4722)40-23-64  
Благовещенск (4162)22-76-07  
Брянск (4832)59-03-52  
Владивосток (423)249-28-31  
Владикавказ (8672)28-90-48  
Владимир (4922)49-43-18  
Волгоград (844)278-03-48  
Вологда (8172)26-41-59  
Воронеж (473)204-51-73  
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06  
Ижевск (3412)26-03-58  
Иркутск (395)279-98-46  
Казань (843)206-01-48  
Калининград (4012)72-03-81  
Калуга (4842)92-23-67  
Кемерово (3842)65-04-62  
Киров (8332)68-02-04  
Коломна (4966)23-41-49  
Кострома (4942)77-07-48  
Краснодар (861)203-40-90  
Красноярск (391)204-63-61  
Курск (4712)77-13-04  
Курган (3522)50-90-47  
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13  
Москва (495)268-04-70  
Мурманск (8152)59-64-93  
Набережные Челны (8552)20-53-41  
Нижний Новгород (831)429-08-12  
Новокузнецк (3843)20-46-81  
Ноябрьск (3496)41-32-12  
Новосибирск (383)227-86-73  
Омск (3812)21-46-40  
Орел (4862)44-53-42  
Оренбург (3532)37-68-04  
Пенза (8412)22-31-16  
Петрозаводск (8142)55-98-37  
Псков (8112)59-10-37  
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15  
Рязань (4912)46-61-64  
Самара (846)206-03-16  
Санкт-Петербург (812)309-46-40  
Саратов (845)249-38-78  
Севастополь (8692)22-31-93  
Саранск (8342)22-96-24  
Симферополь (3652)67-13-56  
Смоленск (4812)29-41-54  
Сочи (862)225-72-31  
Ставрополь (8652)20-65-13  
Сургут (3462)77-98-35  
Сыктывкар (8212)25-95-17  
Тамбов (4752)50-40-97  
Тверь (4822)63-31-35

Тольятти (8482)63-91-07  
Томск (3822)98-41-53  
Тула (4872)33-79-87  
Тюмень (3452)66-21-18  
Ульяновск (8422)24-23-59  
Улан-Удэ (3012)59-97-51  
Уфа (347)229-48-12  
Хабаровск (4212)92-98-04  
Чебоксары (8352)28-53-07  
Челябинск (351)202-03-61  
Череповец (8202)49-02-64  
Чита (3022)38-34-83  
Якутск (4112)23-90-97  
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

эл.почта: [ehr@nt-rt.ru](mailto:ehr@nt-rt.ru) || сайт: <https://endcounters.nt-rt.ru/>